

inka[®]mobile™ CLIP PEN + STYLUS

ATTACHE STYLO ET STYLET
STIFT MIT CLIP UND EINGABESTIFT
BOLÍGRAFO Y LÁPIZ ÓPTICO



Unscrew Quick-Use Pen into components



Remove ink cartridge from Capacitive Stylus Tip and dispose



Replace Capacitive Stylus Tip on new ink cartridge
and reassemble pen components